













Readers and credentials

Compatibility matrix

Bus type	Recommended Bosch Readers	Card format									
		MIFARE DESFire EV1, EV3 (Bosch code)	MIFARE Classic (Bosch code)	iCLASS, iCLASS SE	Seos	LEGIC advant	LEGIC prime	ISO 14443-A CSN	EM card	HID Prox	Mobile credentials
		13.56 MHz					125kHz				
RS-485	LECTUS select BLE 	●	●*			●	●**	●*			●
	LECTUS select 	●	●*			●	●**	●*			
	LECTUS select E 	●	●*								
	Stid Readers (OSDP) ARC1W33BPH5B201A ARCW33APHB201A ARCW33BPHB201A 	●*						●			
Wiegand	LECTUS duo 3000 C LECTUS duo 3000 CK 		●					●			●***
	LECTUS duo 3000 E LECTUS duo 3000 EK 	●	●					●			●***
	ARD-FPBEW2-H3 	●	●	●	●			●	●	●	

* Special configuration is needed
 ** Special configuration needed for LEGIC prime
 *** Only with Wiegand interface

Bus type	Recommended Bosch Readers	Card format									
		MIFARE DESFire EV1, EV3	MIFARE Classic	iCLASS, iCLASS SE	Seos	LEGIC advant	ISO 14443-A CSN	EM card	HID Prox	Mobile credentials	
		13.56 MHz					125kHz				
RS-485	LECTUS secure 1000 SO 					●		●			●***
	LECTUS secure 1000 IC LECTUS secure 3000 IC LECTUS secure 4000 IC LECTUS secure 5000 IC 			●	●			●			●***
	Stid Readers (Wiegand) ARC1R31B103B101A ARCR31A103B101A ARCR31B103B101A 	●	●					●			●
	ARD-AYK12 							●			
Wiegand	ARD Miniprox ARD Entryprox ARD-PROX-PPL 									●	

*** Only with Wiegand interface

Let them in and keep them out.

If you would like to find out more, or want to know how we can help you with your access control needs, please do not hesitate to contact us via sales.ai@keenfinity-group.com or check our website keenfinity-group.com/xc/en/solutions/access-control-systems/

